

be beaten, as speed is essential to a thief the side panels lock will almost certainly mean that he will move on to another machine where the panels can be off in seconds rather than minutes! With a padlock instead of the bolt this device is even better!

Two holes will be found in the rear frame if the number plate is removed, and the angle plate should be bolted on using the screws provided, the number plate replaced. To lock the panel for the wishbone tubes over the tensioner arms and the wishbone to the angle plate by the bolt provided (or a padlock if preferred). Although simple work a little practice, as the bolt or padlock will normally be fitted by feel when the panels are in place, we suggest the first installation with only one panel removed to observe the line up of the wishbone thread and the angle bracket hole.